TECH BRIEF



Benefits

- Discovers and virtually maps
 physical storage
- Replaces manual mapping of
 Fibre Channel LUNs
- Provides consistent drive and shelf LUN mapping
- Eliminates the need to remap Fibre Channel storage if a drive shelf is removed for maintenance or has a failure
- No labor hours required to
 reconfigure LUNs. Better management
 of multiple shelves of storage

Reduce OPEX with XstreamCORE®

Patented Drive Map Director™ Technology Reduces Maintenance Costs

Why Choose XstreamCORE[®] vs. Native Fibre Channel

ATTO XstreamCORE[®] provides features and technologies that enhance and improve direct-attached SAS storage while offering flexibility over native Fibre Channel products. Management and monitoring are two primary functionalities that the XstreamCORE adds to direct-attached storage products. Drive Map Director[™] improves maintenance of storage by lowering overall operating expense (OPEX) costs by reducing the number of labor hours required to setup, manage and maintain storage.

The Challenge

Storage is growing at such a rapid pace that management and maintenance is becoming a larger portion of OPEX budgets. Any time spent maintaining storage reduces ROI by a large margin with continued reconfiguration as the storage topology changes. Managing storage during failure conditions can be costly as IT resources are needed to reconfigure and reassign LUNs to make up for the missing storage.

Tools that help organizations reduce complexity and configuration of storage are needed to help IT resources concentrate on more important issues. Best practice is to have a hardware device that can manage storage topologies without the need for expensive and obtrusive software licensing.

The Solution

Drive Map Director helps to make the ATTO XstreamCORE a simple plug and play type device that helps organizations reduce maintenance costs. OPEX is reduced by eliminating the need to configure LUNs when installing, adding or maintaining storage connected to the XstreamCORE.

No configuration of the XstreamCORE is necessary, just plug in storage, connect to hosts or the SAN and power-on all devices. The operating system will recognize all storage connected to the *i*ntelligent Bridge with no manual intervention needed, which reduces installation labor costs and user error.

About ATTO

For over 30 years, ATTO Technology, has been a global leader across the IT and media & entertainment markets, specializing in network and storage connectivity and infrastructure solutions for the most data-intensive computing environments. ATTO works with partners to deliver end-to-end solutions to better store, manage and deliver data.

All trademarks, trade names, service marks and logos referenced herein belong to their respective companies.

The Power Behind the Storage

Additionally there is no maintenance of the XstreamCORE required when you add new storage or have a drive failure. Simply add storage, replace a drive or a shelf of storage, and you will be up and running with no additional configuration required—a factor that saves a large portion of labor costs annually.

Why XstreamCORE?

ATTO XstreamCORE *i*ntelligent Bridge devices connect low cost SAS disk storage and SAS tape drives to Fibre Channel storage area networks with the added benefit of adding advanced intelligence with advanced management and monitoring to these direct-attached storage devices.

Why ATTO?

ATTO provides a wide range of end-to-end solutions to help customers better store, manage and deliver their data. With a focus toward markets that require higher performance, ATTO manufactures HBAs, *i*ntelligent Bridges, NICs, Thunderbolt[™] adapters and software and distributes globally.

Drive Map Director™

Drive Map Director discovers the physical layout of target devices attached to an *i*ntelligent Bridge or host adapter and then creates a virtual topology of the physical storage. Target device maps corresponding to the physical layout are created with LUNs assigned for each slot in the enclosure. This numbering scheme is static and remains with the shelf and slot location even when a drive or shelf is added or removed.

